

ADDING TRANSMITTERS

Press the start button for 5 seconds and release when the red LED indicator goes out. The LED will flash once to confirm the Add Mode.

Take the new transmitter to be added and press the button once. The red LED indicator should flash once. Repeat this for every new transmitter to be added to the system.

After the last transmitter has been added either wait 30 seconds or press the start push button once to reset to normal operation.

The remote control system uses the latest "rolling code" technology. Hand transmitters supplied are pre-programmed. The receiver can memorise the codes of 15 transmitters.

Thermaglide 