

## Installation Instructions

Seip mains powered receiver & keyfob kit type EKR1MCT with 35cm wire tails



Seip EKR1MCT receiver unit with 35cm wire tails  
(shown with mini & midi keyfob)

© www.Garage-Door-Remotes.co.uk

### Compatibility

Suitable for use with any remote controlled garage door or gate operator with provision for a "open/close" pushbutton control switch (normally open impulse contacts)

The Seip EKR1MCT receiver is compatible with the HomeLink in-car remote system as fitted to Audi, Bentley, BMW, Chrysler, Jaguar, Lamborghini, Maybach, Mercedes-Benz, Opel, Porsche, VW & Vauxhall (car must have Homelink system with software rev. 6 or later)

### Power Requirement

operating voltage range: 220 - 240 Volts

### Connections

Sheathed Blue & Brown wires: 230 volt mains supply (see above)  
Blue wires: Volt free relay contacts (max load 0.5A)  
For direct connection to the "impulse" control circuit of a gate or garage door operator

### Positioning

The receiver unit should be secured in a dry position using the self-adhesive pads supplied. If used with gate equipment it must be housed in a weatherproof enclosure as the receiver is not water resistant. (if installed inside a steel cabinet an external aerial will be required)

### Digital code system

The keyfob transmitters communicate to the receiver by digitally coded transmission. Each transmitter is factory pre-programmed with a unique set of security codes from a choice of 260 million different codes and "hops" to a new code after every operation. The receiver can learn & memorize the unique security code signature of up to sixteen Seip SKR series keyfob transmitters.

### Programming instructions

Your receiver will be pre-programmed ready for use with the key-fob(s) supplied with it, but if any further key-fobs are added these will require programming as follows:

1/ Hold the new keyfob transmitter against the receiver casing beside the antenna and press the button you wish to use until the red light shows. (the mains power must be connected)

2/ Take the keyfob away from the receiver & press the same button again until the red light goes out.

The new fob should now operate your receiver.

Repeat the above procedure for up to sixteen Seip SKR series keyfobs.

### Clearing the memory

(necessary if a key-fob has been lost or stolen)

Take any pre-programmed keyfob transmitter and hold it against the receiver casing beside the antenna and press and hold the programmed button for about ten seconds until the red light goes out. **This will erase all previously memorised fobs, follow the programming instructions above to re-teach your keyfobs**

### Battery Replacement

**Mini type Key-Fob** - Remove the screw from rear casing and prize the two halves of the casing apart to reveal two CR1616 "coin" type batteries

**Midi type Key-Fob** - Prize the two halves of the casing apart to reveal a type LR23A battery.



Seip EKR1MCT single channel  
mains powered radio control system  
**Range - up to 100Mtrs**  
**433Mhz MPT 1340 UK approved frequency**  
CE

**Note:** For best range the antenna (rigid black wire) should be positioned away from any metalwork or wires

**Amourelle Products Limited - The UK's #1 Garage Door Spares & Automation Specialist**

(c) Copyright 2011 Amourelle Products Ltd United Kingdom

**www.Garage-Door-Remotes.co.uk - For technical advice phone: 0118 969 4657**